



Figure 1A	Figure 1B
-----------------------------------	-----------------------------------

For Model Numbers:

8591L	8504L	8591L1	79806	5282LP	9649LP
8591L-048	8171L	8504L1	79807	PNTL	6245LP
8843L	8171L-048xx	8591L1-xxx	79808	KML	2520LC
8841L	8163L	8148L1-xxx	8173L	1263	5303L
8148L-048	8164L	8504L1-xxx	8172L	5282LP	5301L
08504L	8164L1	CD2AL	HVTL	5312L	
	8164-1481	1871	HVTL-P	2228L	

LANGUAGE CONTENTS

English 繁體中文 中文（普通话/简体） 한국어 Bahasa Indonesia	5 8 11 14 17	Bahasa Melayu ไทย Tiếng Việt 日本語	20 23 26 29
--	--	---	--

English

ORIGINAL INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions are required to always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE

DANGER

To reduce the risk of injury or death by electrical shock:

- Do not reach for an appliance that has fallen into water. Unplug immediately from receptacle.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it is able to fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Except when charging, always unplug this appliance from the electrical outlet immediately after using.

LITHIUM-ION BATTERY REPLACEMENT

For battery replacement the entire, intact clipper or trimmer should be sent to your nearest Wahl Clipper Corporation location or taken to a suitably qualified professional. The battery should only be replaced by the original manufacturers spare, for safety reasons a substitute should not be used. This product contains a rechargeable battery that is non-replaceable. Do not attempt to remove the battery. Lithium-ion batteries can explode, catch fire, and/or cause burns if disassembled, damaged or exposed to water or high temperatures.

WARNING

To reduce the risk of burns, fire, electrical shock, or injury to persons:

- This appliance can be used by children aged from 14 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction by a person responsible for their safety, concerning use of the appliance in a safe way and understand the hazards involved. Children should be supervised to ensure that they do not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

- WARNING! HANDLE WITH CARE! INJURIES DUE TO INCORRECT HANDLING**
- Cutting blades may become hot after prolonged use.** (for clippers/ trimmers only)

- This appliance is to be used with the power supply unit or USB charge cable provided with the appliance.

- Using other cords with the charge stand may cause serious injury from electric shock.
- Keep the appliance dry.

- If this appliance has USB-C charging capabilities, use only with a USB Power Source on a certified product, such as a computer, class 2 power supply or automotive adaptor. Never use unapproved USB sources.
- Only replace defect power supply units and USB charge cables with original spare parts, which can be

- 請讀所有有充電說明。對本電器充電以及使用和儲存本電器的溫度範圍為 10~40° C (50~104° F)。不當充電或在不可適宜環境外給產品充電可能損壞電池，增加起火風險。避免將產品暴露於陽光直射下。
- 如果電線損壞或發生洩漏，請避免其接觸皮膚或眼睛。如果出現上述情況，請立即用沖水洗乾淨並尋求醫療救治。
- 為了防止電池發熱或釋放有毒物質，請勿對產品或其電池進行改裝、穿透、破壞、拆解、短路、過度充電或反充電。

- 注意：**腐蝕性化學品危害
- 腐蝕性化學品可能損傷產品及其配件。
- 請勿使用溶劑或粗糙材料。
- 請使用製造商建議的清潔劑和刀片組潤滑油。
- 可透過經銷商或服務中心購買衛生噴霧和刀片組潤滑油。
- 卸除齒面附件。使用清潔劑清潔夾嘴和刀片組刀匣上已剃下的毛髮。
- 僅使用經微潤滑的柔軟織布擦拭產品。
- 請勿將產品或刀片組放入任何液體中。（清潔和護理）。 （仅限理髮剪/修剪器）
- 在定期潤滑和潤滑的情況下，長期使用後潤滑效果仍然下降，則需更換刀片組。

請保留使用說明

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

僱用商業使用

ordered via Wahl service centers.

- Do not use attachments not specified by the manufacturer.
- Never drop or insert any object into any opening.
- Do not hold the appliance by the mains cable to carry it, and do not use the cable as a handle.
- When disconnecting the appliance from the mains, never pull on the mains cable or on the appliance itself.
- Do not hold the mains cable around the appliance.
- Keep the mains cable and appliance away from hot surfaces.
- Make sure that the mains cable is not twisted or kinked when charging or storing.
- If the power supply cord or plug is damaged, when it is not working properly, after it has been dropped or damaged, or after it has been dropped into water, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- If the power supply cord or plug is damaged, when it is not working properly, after it has been dropped or damaged, or after it has been dropped into water, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Do not crush, disassemble, heat above 100° C (212° F), or incinerate the appliance, due to risk of fire, explosion, or burns.
- Use this appliance only for its intended use as described in this manual.
- During use, do not place or leave the appliance where it is expected to be subject to damage by animals or exposed to weather.
- Do not use outdoors or operate while aerosol (spray) products are being used.
- Do not use this appliance with a damaged or broken blade, cutter bar, or attachment, as it has the potential to result in facial injury.
- Always switch the appliance off before storage, as the appliance can fall down due to the vibrations.
- Follow all charging instructions. Charge, use and store the appliance at a temperature between 10-40°C (50-104°F). Charging improperly or at temperatures outside of this specified range may damage the battery and increase the risk of fire. Avoid direct exposure to sunlight.
- If the cutting performance deteriorates after long use despite regular cleaning and oiling, the blade set should be replaced (for clippers/ trimmers only)
- To prevent batteries from heating up or releasing toxic substances, do not modify, pierce, damage, disassemble, short-circuit, overcharge or reverse charge the product or its batteries.

- CAUTION! DANGER FROM AGGRESSIVE CHEMICALS**
- Aggressive chemicals could damage the appliance and accessories.
- Never use solvents or scouring agents.
- Only use cleaning agents and blade set oil recommended by the manufacturer.
- Hygienic spray and blade set oil are available from your dealer or our service centre.
- Remove the attachment comb. Use the cleaning brush to remove any cut hairs from the housing and from the blade set or cutter bar.
- Only wipe the appliance with a soft, slightly damp cloth.
- Oil the blade set with the blade set oil (See Cleaning and Care). (for clippers/ trimmers only)
- If the cutting performance deteriorates after long use despite regular cleaning and oiling, the blade set should be replaced (for clippers/ trimmers only)

SAVE THESE INSTRUCTIONS

FOR COMMERCIAL USE ONLY

Only use hair clippers, trimmers, or shavers to cut human hair, beard hair, and eyebrows. Use animal clippers for trimming purposes only (animal hair and animal fur).

TROUBLESHOOTING/ PROBLEM SOLVING

If your rechargeable cord/recess unit does not seem to be operating or charging properly, please check the following:

- Check the outlet's functionality by plugging another appliance (one you know is in proper working condition) into the outlet.
- Make sure the unit is not connected to a power source that turns itself off when lights are turned off.
- Make sure the unit and power cord contacts are clean and free of hair or other contaminants.
- Verify that the blade assembly moves freely and is mounted properly.
- W

