


Model WSKTL



Scan for Trimming 101





**Not Charging
No Cargando**



**Charging
Cargando**



**Fully Charged
Completamente
Cargada**



NOTE: Plugging in power cord while locked will deactivate the travel lock.

NOTA: Enchufar el cable de alimentación mientras esté bloqueada desactivará el bloqueo de viaje.



This symbol, located on the trimmer, represents that the trimmer is suitable for use in the bath and shower.

Este símbolo, que se encuentra en la recortadora, indica que es apta para su uso en el baño y en la ducha.

LITHIUM-ION BATTERY REPLACEMENT, TRIMMER DISPOSAL AND RECYCLING:

- For battery replacement send the entire, intact trimmer unit to: Wahl Annex 3001 North Locust, P.O. Box 578, Sterling, IL 61081
- Do not attempt to remove the battery. Lithium-Ion batteries can explode, catch fire, and/or cause burns if disassembled, damaged, or exposed to water or high temperatures.
- If you choose not to replace the battery, the entire, intact trimmer unit must be disposed. Do not attempt to remove the battery for disposal. Lithium-Ion batteries may be subject to local disposal regulations. Many locations prohibit disposal in standard waste receptacles. Check your local laws and regulations.
- For recycling contact a government recycling agency, waste disposal service, retailer, or visit online recycling sources, such as www.batteryrecycling.com or www.rbrc.org.

CAMBIO DE LA PILA DE LITIO ION, DESECHO DE LA RECORTADORA Y RECICLAJE:

- Para cambiar la pila, envíele toda la recortadora intacta a: Wahl Annex 3001 North Locust, P.O. Box 578, Sterling, IL 61081
- No intente sacar la pila. Las pilas de litio ion pueden explotar, incendiarse o causar quemaduras si se desarman, se dañan o las exponen al agua o altas temperaturas.
- Si decide no cambiar la pila, debe desechar toda la recortadora. No intente sacar la pila para desecharla. Las pilas de litio ion están sujetas a reglamentos de desechos locales. Muchos lugares prohíben el desecho en recipientes de basura corrientes. Consulte las leyes y reglamentos locales.
- Para el reciclaje, contacte a la agencia de reciclaje gubernamental, el servicio de basuras, el comerciante minorista o las fuentes de reciclaje en línea, tal como www.batteryrecycling.com o www.rbrc.org.

LIMITED LIFETIME WARRANTY ON BLADES

Valid in U.S.A. Only

If the blades fail to operate satisfactorily during the life of your Wahl product, Wahl will, at its option, repair or replace the blades.

5-YEAR LIMITED WARRANTY ALL OTHER COMPONENTS

Valid in U.S.A. Only

This warranty covers any defects in materials or workmanship on any other component. If a defect occurs during the first five years following the initial purchase date, Wahl will, at its option, repair or replace the product and return it to you FREE OF CHARGE.

HOW TO GET WARRANTY SERVICE

Do not return this product to store where purchased. Products needing repair under this warranty should be returned with postage pre-paid to the following address or call 1-800-767-9245 for assistance:

Wahl Clipper Corp., Attn: Repair Department, 3001 Locust Street, Sterling, IL 61081
When mailing, please include a note describing the defect and the date of original purchase or receipt as a gift. Products out of warranty will be repaired at our standard repair charges.

WHAT THESE WARRANTIES DO NOT COVER

This warranty does not cover products damaged by:

1. Modification or repair by anyone other than Wahl Clipper Corporation or a Wahl authorized service center;
2. Commercial (non-consumer) use or unreasonable use.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No other written express warranty is given. No responsibility is assumed for incidental or consequential damages of any type or for the use of unauthorized attachments. Some states may not allow the exclusion or limitation of incidental or consequential damages, so the limitation may not apply to you. Warranty valid in U.S.A. only. Outside U.S.A., check with store for Wahl authorized distributor's warranty.

SERVICE AND REPAIR

If you have problems with your trimmer, send it prepaid with a note explaining the problem to:

Wahl Clipper Corp., Attn: Repair Department, 3001 Locust Street, Sterling, IL 61081
Telephone (800) 767-9245

For products purchased outside the United States, contact your distributor.

60 DAY MONEY BACK GUARANTEE!

If for any reason within 60 days of purchase of your Wahl® trimmer you are not satisfied with your trimmer and would like a refund, just return your trimmer, together with the sales receipt, to the retailer from whom you purchased it. Wahl will reimburse all retailers who accept trimmers within 60 days of purchase. If you have any questions regarding this money-back guarantee, please call 1-800-767-9245 in the United States.

The trimmer you purchased may not have all of these heads, but they will all work with your trimmer if you wish to purchase them. You may order additional heads online at www.WahlUSA.com.

For more information or Product Registration, visit WahlUSA.com

GARANTÍA LIMITADA DE POR VIDA EN CUCHILLAS

Válida en EE. UU. Solamente

Si las cuchillas no funcionan de manera satisfactoria durante la vida útil de su producto Wahl, Wahl procederá, a su elección, a reparar o reemplazar las cuchillas.

GARANTÍA LIMITADA POR 5 AÑOS EN TODOS LOS DEMÁS COMPONENTES

Válida en EE. UU. Solamente

Esta garantía cubre todos los defectos de materiales y mano de obra de todos los demás componentes. En caso de producirse algún defecto durante los primeros cinco años luego de la fecha de compra inicial, Wahl procederá, a su elección, a reparar o reemplazar el producto y se lo devolverá SIN CARGO.

CÓMO OBTENER EL SERVICIO DE LA GARANTÍA

No devuelva este producto a la tienda donde fue adquirido. Los productos que necesiten ser reparados conforme a esta garantía deben enviarse con franqueo pagado a la siguiente dirección o llame al 1-800-767-9245 para obtener asistencia:

Wahl Clipper Corp., Attn: Repair Department, 3001 Locust Street, Sterling, IL 61081
Cuando envíe un correo, incluya una nota que describa el defecto y la fecha original en que se compró o se recibió como regalo. Los productos fuera de garantía se repararán aplicando nuestros cargos de reparación estándar.

Esta garantía no cubre los productos dañados por las siguientes causas:

QUÉ ES LO QUE NO CUBREN ESTAS GARANTÍAS

Esta garantía no cubre los productos dañados por las siguientes causas:

1. Modificación o reparación efectuada por otra persona que no pertenezca a Wahl Clipper Corporation ni a un centro de servicio autorizado por Wahl;
2. Uso comercial (no de consumidor) o no razonable.

Esta garantía le otorga derechos legales específicos y usted también puede tener otros derechos que varían en cada estado. No se otorga ninguna otra garantía explícita por escrito. No se asume responsabilidad alguna por daños indirectos o consecuentes de cualquier tipo, ni por el uso de accesorios no autorizados. Algunos estados pueden prohibir la exclusión o la limitación de daños indirectos o consecuentes, de modo que esta limitación puede no aplicarse a su caso. Garantía sólo válida en EE. UU. Fuera de EE. UU., consulte en la tienda sobre la garantía del distribuidor autorizado de Wahl.

SERVICIO Y REPARACIÓN

Si tiene problemas con la recortadora, envíela con franqueo prepago y una nota explicando el problema a: **Wahl Clipper Corp., Attn: Repair Department, 3001 Locust Street, Sterling, IL 61081, Teléfono (800) 767-9245.** Para productos comprados fuera de Estados Unidos, póngase en contacto con su distribuidor.

¡GARNATÍA 60 DIAS PARA DEVOLUCIÓN DE SU DINERO!

Si por cualquier razón entre los 60 días de la compra de su recortadora de Wahl no está satisfecho con su compra y desea una devolución de su dinero, regrese la recortadora junto con su recibo de compras a la tienda donde lo compro. Wahl reembolsara a las tiendas quienes acepta las recortadoras entre los 60 días de su compra. Si tiene preguntas tocantes esta garantía, por favor llamanos al 1-800-767-9245 en los Estados Unidos.

La recortadora que usted compró no puede tener todas estas cabezas incluidas, pero todas las cabezas trabajan con su recortadora si desea comprarlas. Puede hacer pedidos de cabezales adicionales en línea, en www.WahlUSA.com.

Para mas informacion o Registracion de Producto visite WahlUSA.com