

Wahl® Hot-Cold Neck & Shoulder Vibrating Wrap Quickstart Guide




Insert two AA batteries (not included).



If hot or cold is desired, heat or freeze the gel pack. See *SPECIAL INSTRUCTIONS*.




Place gel pack in the zippered pocket on the upper back of the wrap.



Place vibrating wrap around the neck, using the magnetic closures to fasten in place. To turn the unit on, press the power button once.




To change the intensity, press the power button. Select a high or low setting by pressing the power button successively.



To turn the unit off, hold the power button for 3 seconds. This unit automatically turns off after 20 minutes.

Wahl® Hot-Cold Neck & Shoulder Vibrating Wrap Key Features



VIBRATING NODES massage to deliver powerful relief for neck, back, and shoulder pain.

MAGNETIC CLOSURES hold the wrap in place. Make sure the unit is flush with the chair or seat to allow for correct massage ergonomics.

ADD HEAT for a gentle warmth to enhance blood circulation and soothe aching muscles.

ADD COLD to aid acute and chronic pain, muscle pain, arthritis, inflammation, swelling, and injury recovery.